

140-140-009	Планка	БЧ	x	x															
140-141-000	Барабан ПИСТА	2				x	x	x	x										
140-141-000-01										x	x	x	x	x	x	x			
140-141-000-02																			x
140-141-001	Ось	БЧ				x	x	x	x	x	x	x	x	x	x	x			
140-141-001-01		БЧ																	x
140-141-002	Обечайка	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	x	x
140-141-003	Фланец	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	x	x
140-141-004	Фланец	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	x	x
140-141-005	Конус	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	x	x
140-141-006	Кольцо	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	x	x
140-141-007	Накладка	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	x	x
140-141-008	Планка	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	x	x
140-150-000	Ступица					x	x	x	x	x									
140-150-001	Палец					x	x	x	x	x	x	x	x	x	x	x	x	x	x
140-150-002	Ступица	БЧ				x	x	x	x	x									
140-151-000	Ступица									x	x	x	x	x	x	x	x	x	
140-151-001	Ступица	БЧ								x	x	x	x	x	x	x	x	x	
140-160-000	Колесо коническое					x	x	x	x	x	x	x							
140-160-001	Венец зубчатый	БЧ				x	x	x	x	x	x	x							
140-160-002	Ступица	БЧ				x	x	x	x	x	x	x							
140-170-000	Ролик																		
140-170-001	Обод	БЧ																	
140-170-002	Ступица	БЧ																	
057-160-000	Ролик									x	x	x	x	x		x	x	x	
057-160-001	Обод	БЧ								x	x	x	x	x		x	x	x	
057-160-002	Ступица	БЧ								x	x	x	x	x		x	x	x	
140-171-000	Ролик															x			

СЗЧ барабана

027-222-100	Колодка тормозная		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	027-222-100
027-220-101	Заклёпка		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
027-222-101	Лента асбестовая тормозная	БЧ	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
027-222-110	Колодка		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	027-222-110
027-222-111	Ребро		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
027-222-112	Лист	БЧ	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
027-222-113	Втулка	БЧ	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-221-000	Сменные детали тормоза			x	x	x	x											140-221-000
140-221-000-01								x	x	x								
140-221-000-02											x	x						
140-221-000-03													x					
140-221-000-04														x	x	x		
140-221-001	Палец			x	x	x	x	x	x	x				x	x	x	x	
140-221-001-01				x	x	x	x	x	x	x	x	x						
140-221-001-02				x	x	x	x											
140-221-001-03				x	x	x	x											
140-221-001-04				x	x	x	x								x*	x*	x*	
140-221-001-05				x	x	x	x											
140-221-001-06								x	x	x	x	x						
140-221-001-07								x	x	x	x	x						
140-221-001-08								x	x	x	x	x						
140-221-001-09														x	x*	x*	x*	
140-221-002	Палец			x	x	x	x	x	x	xx	x	x						
140-221-003	Ось			x	x	x	x											
140-221-004	Ось							x	x	x	x	x						
140-230-000	Муфта тормозная		x	x	x	x	x	x	x	x	x	x						140-230-000
140-230-000-01													x					
140-230-001	Полумуфта тормозная		x	x	x	x	x	x	x	x	x	x	x					
140-230-002	Палец		x	x	x	x	x	x	x	x	x	x	x					
140-230-003	Втулка		x	x	x	x	x	x	x	x	x	x	x					

С34 тормоза

тозной

140-300-014	Ось полая					x	x	x	x	x	x	x	x	x*				
140-300-015	Втулка		x	x	x													
140-300-016	Втулка		x	x	x													
140-300-017	Ось				x													
140-300-018	Шкив тормозной					x	x	x	x	x	x							
140-300-018-01												x						
140-300-018-02														x	x	x	x	
140-300-020	Ролик													x	x*			
140-300-021	Ось													x	x*			
140-300-022	Втулка													x	x*			
140-300-024	Ось																x	x
140-300-025	Ось																x	x
175-300-002	Колесо										x*	x	x	x	x	x	x	
175-300-002-01	Колесо										x*	x	x	x	x	x	x	
175-300-005	Колесо зубчатое														x	x	x	
175-300-006	Башмак														x*	x	x	
140-360-000	Ось полая					x	x	x	x	x	x	x	x	x	x	x	x	140-360-000
140-360-001	Корпус	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	
140-360-002	Обеайка	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	
140-360-003	Стенка	БЧ				x	x	x	x	x	x	x	x	x	x	x	x	
140-310-000	Сменные детали тележки противовеса кабеля		x	x	x													140-310-000
140-310-000-01						x												
140-310-000-02							x	x	x	x	x	x						
140-310-000-03														x				
140-310-000-04															x	x	x	
140-310-001	Блок		x	x	x													
140-310-001-01						x	x	x	x	x	x	x	x	x	x	x	x	
140-310-002	Ролик		x	x	x	x												
140-310-002-01														x	x*	x*	x*	
140-310-002-02															x*	x*	x*	
140-310-003	Ось		x	x	x	x												
140-310-003-01														x	x*	x*	x*	
140-310-003-02															x*	x*	x*	

СЗЧ тележки противовеса кабеля

140-441-004	Стенка									x	x	x	x	x	x	x	x	x
140-441-004-01	Стенка									x	x	x	x	x	x	x	x	x
140-441-005	Ребро									x	x	x	x	x	x	x	x	x
140-441-006	Ребро									x	x	x	x	x	x	x	x	x
140-441-007	Лист									x	x	x	x	x	x	x	x	x
Стреловое устройство																		
140-500-000	Сменные детали стрелового устройства 2 ЛИСТА		x															140-500-000
140-500-000-01				x														
140-500-000-02					x													
140-500-000-03						x												
140-500-000-04							x	x										
140-500-000-05									x									
140-500-000-06										x								
140-500-000-07											x	x	x	x	x	x	x	
140-500-001	Ось		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-500-002	Ось		x	x														
140-500-003	Ось				x	x	x	x	x	x	x	x	x	x	x	x	x	
140-500-004	Ось		x	x														
140-500-005	Ось				x													
140-500-005-01						x	x	x										
140-500-005-02									x	x	x	x	x	x	x	x	x	
140-500-006	Ось		x															
140-500-007	Ось			x	x	x	x	x										
140-500-007-01									x	x	x	x	x	x	x	x	x	
140-500-008	Ось		x															
140-500-009	Ось			x	x	x	x	x										
140-500-010	Ось		x	x	x	x	x	x										
140-500-010-01									x	x	x	x	x	x	x	x	x	
140-500-011	Ось								x	x	x	x	x	x	x	x	x	
140-530-002-01	Втулка		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-530-002-02			x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-530-002-03			x	x	x	x	x	x										
140-530-002-04			x	x	x	x	x	x										
140-530-002-05			x	x	x	x	x	x										
140-530-002-06			x	x	x	x	x	x										
140-530-002-07									x	x	x	x	x	x	x	x	x	
140-530-002-08									x	x	x	x	x	x	x	x	x	

СЗЧ стрелового устройства

140-550-004	Спица	БЧ	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x		
140-560-000	Блок		x																140-560-000
140-560-001	Обод	БЧ	x																
140-560-002	Ступица	БЧ	x																
140-560-003	Спица	БЧ	x																
140-560-004	Спица	БЧ	x																
140-561-000	Блок			x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	140-561-000
140-561-001	Обод	БЧ		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-561-002	Ступица	БЧ		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-561-003	Спица	БЧ		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-561-004	Спица	БЧ		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-570-000	Сменные детали направляющего ролика		x																140-570-000
140-570-001	Ось		x																
140-570-100	Ролик		x																140-570-100
140-570-101	Гильза	БЧ	x																
140-570-102	Бандаж	БЧ	x																
140-571-000	Сменные детали направляющего ролика			x															140-571-000
140-571-001	Ось			x															
140-571-002	Ролик			x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-571-002-01				x															
140-572-000	Сменные детали направляющего ролика				x	x	x	x	x	x	x	x	x	x	x	x	x	x	140-572-000
140-571-002-02	Ролик				x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-572-001	Ось				x	x	x	x	x	x	x	x	x	x	x	x	x	x	
140-573-000	Сменные детали направляющего ролика				x	x	x	x	x	x	x	x	x	x	x	x	x	x	140-573-000

СЗЧ шарнирного сочл

СЗЧ направляющего ролика

